

## ASSEMBLY OF THE CLIPPING CRATE BOX

**1** Location and components :

CLIPS/STAPLES  
(units by reference  
of clipping crate acquired)

BASE/COVER  
(2 UNITS)

SIDE  
(Touchdown 4; in the  
2 long et 2 shorts)

12 mm

12 mm

**2** Place the base on the floor and locate the first sample at the end of the run (the inner edge of 12 is always left and the edge at the base):

1°

12 mm

Trick

12 mm

BASE

SIDE

**3** Continue to place the rest of sides in opposite direction to watch, watching the right location of the inner lace of 12 mm (always on the left):

2°

1°

SIDE

BASE

Trick

SIDE

BASE

**4** Always place the clips from the inside slot until it fits into the adjacent side slot:

clippingcrate

1

2

**5** Once the load is introduced and secured within it, close the clipping crate box by placing the lid and clips corresponding to:

clippingcrate

**6** Important : place each staple at about 10 cm (approx.) from each corner of the box, and distribute the remaining staples preferably on the longer sides:

10 cm (approx)

10 cm (approx)

## DISASSEMBLY OF THE CLIPPING CRATE BOX

Remove each clip with a screwdriver (or other staple). We advise to follow a reverse disassembly order to the assembly order: thus, it will be easier to organize the material.



Hold the staple with your hand during extraction.



Would you like to know more about how to assemble our boxes? You can watch the video via the QR.

